Component interconnection

Anderson connector color code:

Red: 36 V power or 36 V battery charge.

Orange: 12 V power Pink: 5 V power Black: Ground

Green: Brake or Phase A or joystick center

Blue: Throttle or Phase B Yellow: Steer or Phase C

Hub motor



Original connections may be used, but have replaced with Anderson connectors for better robustness. Connects to Motor Controller.

Green	Blue	Yellow
Phase A power	Phase B power	Phase C power

Pink (Red in photo)	Green	Blue	Yellow	Black
5 V	Phase A signal	Phase B signal	Phase C signal	Ground

Motor Controller

Connects to Hub motor

Green	Blue	Yellow
Phase A power	Phase B power	Phase C power

Pink	Green	Blue	Yellow	Black
5 V	Phase A signal	Phase B signal	Phase C signal	Ground

Connects to Switched 36 V supply from C2 Dual Mode

Red	Black		
36 V	Ground		

Connects to throttle of C2 Dual Mode or conventional E-bike throttle.

Pink	Black
5 V	Ground
Red	Blue
Battery Charge	Throttle



Throttle

Connects to Motor Controller. This is used only for testing. In the automated system, C2 Dual Mode replaces the throttle.





Red	Blue
Battery Charge	Throttle
Pink	Black
5 V	Ground

Joystick



Connects to C2 Dual Mode

Commetts to C2 Data	111040	
Yellow Left-right motion (steer)	Green Center	Blue Up-down motion (throttle/brake)
Pink 5 V	Brown Reserved	Black Ground

C2 Dual Mode

Connects to joystick

Pink	Brown	Black
5 V	Reserved	Ground
Yellow Left-right motion (steer)	Green Center	Blue Up-down motion (throttle/brake)

Connects to Motor Controller

Red	Blue
Battery Charge	Throttle

Pink	Black
5 V	Ground

Connects to Motor Controller

Red	Black
36 V	Ground

Connects to Battery

Red	Black	Orange	
36 V	Ground	12 V	
30 V	Ground	12 V	

Connects to C1

Yellow	Green	Blue
steer	Brake	Throttle
Pink	Purple	Black
5 V	Reserved	Ground





Front panel switches:

On: Turns on 5V, 12V and 36V power also requires key switch on motor controller.

Stop: Momentary switch; may also be activated wirelessly.

Cruise: Momentary switch; may also be activated wirelessly.

Motor: Enables computer control of motor; when off, motor is controlled by joystick.

Brake: Enables computer control of brakes; when off, brakes are controlled by joystick.

Steer: Enables computer control of steering; when off, steering is controlled by joystick.

Top LEDs show battery charge.

Ten lower LEDs include internal Stop and Cruise that match the switch state. An LED marked "Reverse" is reserved. The other 7 LEDs may either come internally from C2 or externally from other microprocessors.

LED input connections are:

Green. 4 Blue. 5 Furple. 1		Green: 4	Blue: 3	Purple: 1
----------------------------	--	----------	---------	-----------

Yellow: 5	Brown: 6	Gray: 7	White: 8
		J	

LED output connections are:

Yellow: 5	Brown: 6	Gray: 7	White: 8
	Green: 4	Blue: 3	Purple: 1

Servos




The brake servo pushes a brake lever that connects to disk brakes on the left and right wheels. The pusher is a slotted PVC tube designed so that the rider can use the lever as an emergency brake. Brake lever and servo are between the rider's legs.

Steering servo is linked to the tie bar connecting the front wheels. It is under the seat. Both servos are cabled directly to controllers inside the C2 box.

C1 and C3 Pilot

This is the lowest level of computer control.



Connects to C2

Pink	Purple	Black
5 V	Reserved	Ground
Yellow	Green	Blue
steer	Brake	Throttle

C6 Navigator

Contains shield with GPS logger and SD card.

